


Base Unit 2D and 4D - Cleaning the air conditioner of the airpointer

1- Tools you will need

- Screwdriver Hollow Torx size T25
- A soft brush

2- Locate the grilles of the inlets at the bottom of the airpointer: the one on the left in the photo below is the pump room inlet, the one in the middle the sample fan outlet, and the one on the right is the AC inlet



Ventilation grids of the airpointer

3- Unscrew the holding screws of the 3 grilles (six each)

4- Remove the grilles

5- Clean the inner grids by blowing dust away with low pressure compressed air. Use a soft paint brush to remove stubborn dirt

6- Reinstall the grilles and fasten the screws